


## ASSEMBLY INSTRUCTIONS



TO assemble safety cables:  
 1. Join fixture safety cables with safety cable from ceiling.  
 2. Wrap both safety cable around the cable lock nut.  
 3. Insert screws into both holes on cable lock nut, secure screws with screwdriver.  
 4. Push the cable lock nut into outlet box.

Crystal A1 42PCS	Crystal A2 52PCS	Metal Panel A3 26PCS	Metal Panel A4 20PCS	Metal Panel A5 16PCS	Metal Panel A6 32PCS	PLIER

## Ambrois Medium Chandelier

Item # ARN 5145

WE RECOMMEND INSTALLATION OF THIS LIGHTING FIXTURE BE DONE BY A LICENSED ELECTRICIAN.

**WARNING\*\*\*SWITCH OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER BEFORE INSTALLATION.**

**INSPECT ITEM CAREFULLY BEFORE ATTEMPTING TO INSTALL. IF THERE IS ANY DAMAGE OR OBVIOUS DEFECT. DO NOT INSTALL.**

**ITEM MAY NOT BE RETURNED ONCE IT HAS BEEN INSTALLED.**

**NOTE: CAREFULLY UNPACK EACH PIECE IN TOP LAYER OF PACKING PRIOR TO REMOVING. RETAIN ALL PACKING MATERIAL UNTIL INSPECTION AND INSTALLATION ARE FINAL.**


- Carefully remove all parts from the box.
- A 1/4" threaded nipple must be installed in your outlet box. Then install the threaded nipple (B) into the outlet box.
- Unscrew the threaded collar on the chain end link (G) and attach it to the top ring (H). Close the threaded collar to secure the fixture body.
- Let canopy (D) and lock collar (E) go through the chain (F).
- With the fixture dimension as a guide, shorten the chain (F) as needed using a pair of chain pliers.
- Unscrew the threaded collar on the other chain end link, raise the fixture then attach chain end link to the ceiling loop (C). Close the threaded collar to secure.
- Unwrap the wiring from the top of the fixture body. Weave the power supply cord and the ground wire through the chain (F).
- When you reach the canopy and ceiling loop, measure the wires then cut. Be certain to leave enough to connect inside of the outlet box.
- Strip the insulation back on the two power supply wires about 5/8".
- Twist the power supply and ground wire together and push through the center hole of the ceiling loop (C).
- Connect the fixture Ground (bare) wire with the ground wire from the outlet box using wire nut (A). If your house does not have ground wire, then attach this wire to the green grounding screw inside of the outlet box.
- Connect the fixture Neutral (ribbed, no markings) wire with the neutral wire from the outlet box using wire nut (A).

IT IS IMPERATIVE THAT THIS FIXTURE BE GROUNDED.



VISUAL COMFORT & Co. Est. 1987

ASSEMBLY INSTRUCTIONS



TO assemble safety cables:  
1.Join fixture safety cables with safety cable from ceiling.  
2.Wrap both safety cable around the cable lock nut.  
3.Insert screws into both holes on cable lock nut,secure screws with screwdriver.  
4.Push the cable lock nut into outlet box.



Ambrois Medium Chandelier

Item # ARN 5145

WE RECOMMEND INSTALLATION OF THIS LIGHTING FIXTURE BE DONE BY A LICENSED ELECTRICIAN.

WARNING\*\*\*SWITCH OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER BEFORE INSTALLATION.

INSPECT ITEM CAREFULLY BEFORE ATTEMPTING TO INSTALL. IF THERE IS ANY DAMAGE OR OBVIOUS DEFECT. DO NOT INSTALL.

ITEM MAY NOT BE RETURNED ONCE IT HAS BEEN INSTALLED.

13. Connect the fixture Hot (smooth edge,markings) wire with the hot wire from the outlet box using wire nut (A).
- DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS OR SAFETY WILL BE COMPROMISED.
14. Tuck these wire connections neatly into the outlet box to secure.
15. Put canopy (D) to ceiling loop (C),and secure with lock collar (E).
16. Insert bulbs (not included) into the sockets.
17. Attach the crystal drop (A1) on the metal bar (I) with little pin and plier.
18. Hang the metal panel (A5) on the metal bar (I).
19. Attach the crystal drop (A2) on the metal bar (J) with little pin and plier.
20. Hang the metal panel (A6) on the metal bar (J).
21. Attach the crystal drop (A2) and metal panel (A4) on the metal ring (K) with little pin and plier.
22. Attach the crystal drop (A1) and metal panel (A3) on the metal ring (L) with little pin and plier.
23. Attach the crystal drop (A1) and metal panel (A3) on the metal ring (M) with little pin and plier.
24. Installation is complete,turn on power at fuse or circuit breaker.

\*\*\*Clean with a dry,soft cloth only.Use no harsh abraslves or chemical agents.

Crystal A1 42PCS	Crystal A2 52PCS	Metal Panel A3 26PCS	Metal Panel A4 20PCS	Metal Panel A5 16PCS	Metal Panel A6 32PCS	PLIER

