
ASSEMBLY INSTRUCTIONS



Cavanagh Medium Lantern Sconce

Item # KS 2143

WE RECOMMEND INSTALLATION OF THIS LIGHTING FIXTURE BE DONE BY A LICENSED ELECTRICIAN.

WARNING***SWITCH OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER BEFORE INSTALLATION.

INSPECT ITEM CAREFULLY BEFORE ATTEMPTING TO INSTALL. IF THERE IS ANY DAMAGE OR OBVIOUS DEFECT. DO NOT INSTALL. ITEM MAY NOT BE RETURNED ONCE IT HAS BEEN INSTALLED.

- 1. Carefully remove all parts from the box.
- 2. Remove the backplate (F) from the fixture (H) by loosening screws (I).
- 3. Remove the mounting plate (C) from the backplate (F) by loosening screws (G).
- 4. Affix the anchors (B) to the wall.
- 5. Affix mounting plate (C) to the outlet box and secure with mounting screws (D).
- 6. Affix mounting plate (C) to the wall by screws (E)
- Connect the hot wire (BLACK) from the fixture to the hot wire from the outlet box (usually BLACK). Fasten them together with a plastic wire connector (A) provided and wrap the connection with electrical tape.
- 7. Connect the neutral wire (WHITE) from the fixture to the wire from the outlet box (usually WHITE).

DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS OR SAFETY WILL BE COMPROMISED.

 Connect ground wire from the fixture (bare copper) to ground wire from the outlet box (usually green or copper in color).

IT IS IMPERATIVE THAT THIS FIXTURE BE GROUNDED.

- 9. Attach the backplate (F) to the mounting plate (C) by screws (G).
- 10. Attach the fixture (H) to the backplate (F) by screws (I).
- 11. Insert bulbs (not included) into the socket.
- 12. Installation is complete, turn on power at fuse or circuit breaker.

***Clean with a dry, soft cloth only. Use no harsh abrasives or chemical agents.



