


## ASSEMBLY INSTRUCTIONS



## Liaison Long Pendant Item # KW 5118

**WE RECOMMEND INSTALLATION OF THIS LIGHTING FIXTURE BE DONE BY A LICENSED ELECTRICIAN.**

**WARNING \*\*\* SWITCH OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER BEFORE INSTALLATION.**

**INSPECT ITEM CAREFULLY BEFORE ATTEMPTING TO INSTALL. IF THERE IS ANY DAMAGE OR OBVIOUS DEFECT, DO NOT INSTALL.**

**ITEM MAY NOT BE RETURNED ONCE IT HAS BEEN INSTALLED.**

1. Carefully remove all parts from the carton.
2. Thread pole (H) into the top joint of shade cap (J) by turning clockwise direction until tight.
3. Thread joint (G) onto the top nipple of pole (H) by turning clockwise direction until tight.
4. Thread pole (F) into the top opening of joint by turning clockwise direction until tight.
5. Unscrewing canopy ring (E), slide canopy ring (E) and canopy (D) on pole (F).
6. Attach mounting strap (A) to ceiling outlet box and secure with mounting screws (B).
7. Insert top thread nipple (C) in mounting strap (A).
8. Thread the top nipple of pole (F) into mounting loop (C) by turning clockwise direction until tight.
9. Attach the bare copper ground from the fixture to the ground junction box wire (usually green or copper), fasten together with a plastic wire connector. Tighten wrap the wire connector with electrical tape. Be sure no wire strands are exposed. IT IS IMPERATIVE THAT THE OUTLET BOX IN YOUR HOME BE PROPERLY GROUNDED.
10. Connect neutral wire from fixture (ridges molded wire) to the neutral wire from the junction box (usually white) . Fasten both wires together with a plastic wire connector and tightly wrap the wire connector with electrical tape. Be sure no wire strands are exposed.
11. Connect the hot wires from the fixture (smooth wire) to the hot wire (usually black ) from the junction box. Fasten each together with a plastic wire connector and wrap the connection with electrical tape. DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS OTHERWISE SAFETY WILL BE COMPROMISED.
12. Tuck the wire connections neatly into the ceiling outlet box.
13. Slip canopy (D) to ceiling and secure with canopy ring (E).
14. Insert light bulbs into socket.
15. Loosen set screws (I) from shade cap (J), attach glass shade (K) to shade cap (J), aligning the holes on shade cap (J) with the holes on glass shade (K) and secure with set screws (I). DO NOT OVER TIGHTEN OTHERWISE GLASS WILL BE DAMAGE.
16. Restore power and test fixture. Installation is completed.

\*\*\* Clean with a dry, soft cloth only. Use no harsh abrasives or chemical agents.