
ASSEMBLY INSTRUCTIONS









Eyre Large Hanging Shade

Item # KS 5082

WE RECOMMEND INSTALLATION OF THIS LIGHTING FIXTURE BE DONE BY A LICENSED ELECTRICIAN.

WARNING***SWITCH OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER BEFORE INSTALLATION.

INSPECT ITEM CAREFULLY BEFORE ATTEMPTING TO INSTALL. IF THERE IS ANY DAMAGE OR OBVIOUS DEFECT. DO NOT INSTALL.

ITEM MAY NOT BE RETURNED ONCE IT HAS BEEN INSTALLED.

NOTE: CAREFULLY UNPACK EACH PIECE IN TOP LAYER OF PACKING PRIOR TO REMOVING. RETAIN ALL PACKING MATERIAL UNTIL INSPECTION AND INSTALLATION ARE FINAL.

- 1. Carefully remove all parts from the box.
- 2. Put the linen shade (I) on the top of the metal plate (J).
- 3. Feed the fixture wires and safety cable through the rod (H), then thread the rod (H) to the top of the metal plate (J).
- 4. Feed the fixture wires and safety cable through the collar ring (G), canopy (F) and rod (E), then thread the rod (E) to the rod (H).
- 5. Install the mounting plate (B) to the junction box with the mounting screws (C) provided.
- 6. Connect the safety cables as shown in figure.
- Wrap the fixture ground wire to the green ground screw on the mounting plate (B) and secure, then connect to the ground wire in the junction box using the wire nut (A).
 IT IS IMPERATIVE THAT THIS FIXTURE BE GROUNDED.
- 8. Connect the fixture white wire to the neutral wire in the junction box using the wire nut (A).
- Connect the fixture black wire to the hot wire in the junction box using the wire nut (A).
 DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS OTHERWISE SAFETY WILL
 BE COMPROMISED.
- 10. Install the canopy (F) to the mounting plate (B) and secure with the collar ring (G).
- 11 Insert bulb (not included) into the socket.
- Raise the linen shade (I), then attach the glass shade (L) to the metal plate (J) and secure
 with the thumbscrews (K), then slide down the linen shade (I).
 DO NOT OVER-TIGHTEN THUMBSCREWS, OTHERWISE GLASS COULD BECOME
 DAMAGED.
- 13. Installation is complete, turn on power at fuse or circuit breaker.

^{***}Clean with a dry, soft cloth only. Use no harsh abrasives or chemical agents.

