


RL 11165

ASSEMBLY & INSTALLATION GUIDE



INSPECT ITEM CAREFULLY BEFORE ATTEMPTING TO INSTALL. IF THERE IS ANY DAMAGE OR OBVIOUS DEFECT, DO NOT INSTALL.

ITEM MAY NOT BE RETURNED ONCE IT HAS BEEN INSTALLED.

1. Carefully remove all parts from the carton.
2. Join parts (C), (D) & (E) together, letting rod on bottom of pole (C) pass through center holes on base (D) and base loader (E).
3. From the underside of base, slide the washer (F) over the threaded rod and then thread nut (G) onto the rod. Use the open wrench (H) provided to tighten the nut securely while holding the pole (C).
4. Insert knob (L) into socket.
5. Remove plastic cover (K) from electrical plug (J).
6. Insert light bulb into socket.
7. Plug lamp into electrical outlet.

ADJUSTMENT INSTRUCTION:

1. Loosen break (B).
2. Adjust lamp pole (A) up or down to get desired height.
3. Tighten break (B).

***Clean with a dry, soft cloth only. Use no harsh abrasives or chemical agents.