


RL1250

ASSEMBLY & INSTALLATION GUIDE



INSPECT ITEM CAREFULLY BEFORE ATTEMPTING TO INSTALL. IF THERE IS ANY DAMAGE OR OBVIOUS DEFECT, DO NOT INSTALL.

ITEM MAY NOT BE RETURNED ONCE IT HAS BEEN INSTALLED.

1. Join parts (H), (J) & (K) together, letting threaded rod on bottom of pole (H) pass through the center hole of bases (J) & (K), slide washer (L) over threaded rod, follow with nut (M) and tighten the nut with wrench (N) provided.
2. Place lamp shade (A) over top of threaded socket (B), and secure with lamp shade.
3. Insert light bulb into socket.
4. Remove plastic cover (P) from electrical plug (O).
5. Plug lamp into wall outlet.
6. ADJUSTMENT INSTRUCTIONS
 1. Loosen adjustment collar (G) by turning in counter clockwise directions.
 2. Adjust lamp by pulling or pushing upper pole (F) up or down to desired height.
 3. Tighten the adjustment collar.And/Or
 1. Loosen adjustment keys (E) and (C).
 2. Adjust lamp pole (D) and the socket (B) to desired position.
 3. Tighten the adjustment keys

R A L P H L A U R E N