

## INSPECT ITEM CAREFULLY BEFORE ATTEMPTING TO INSTALL. IF THERE IS ANY DAMAGE OR OBVIOUS DEFECT, DO NOT INSTALL.

## ITEM MAY NOT BE RETURNED ONCE IT HAS BEEN INSTALLED.

- 1. Loosen knobs (D) on harp (B).
- 2. Remove Harp (B) from plastic bag and slide into top of harp holder (A).
- 3. Adjust Harp (B) up or down to get desired height.
- 4. The socket can not show under the shade (E) after the harp is adjusted correctly.
- 5. Put shade (E) (not included) onto the top of harp (B).
- 6. Carefully tighten knobs (D) on harp (B).
- 7. Plug into proper electrical outlet and test fixture.
- 3. Assembly is complete.