


## ASSEMBLY INSTRUCTIONS



## Talisman Large Floor Lamp Item # S1430

**INSPECT ITEM CAREFULLY BEFORE ATTEMPTING TO INSTALL. IF THERE IS ANY DAMAGE OR OBVIOUS DEFECT, DO NOT INSTALL.**

**ITEM MAY NOT BE RETURNED ONCE IT HAS BEEN INSTALLED.**

1. Carefully remove all parts from the carton.
2. Join lamp stem (E) and lamp base (F) together, letting bottom nipple of the lamp stem (E) pass through the hole of lamp base (F) and metal disk (G). Make sure the small nipple (J) pass through the small hole on lamp base (F).
3. From the underside of base (F), slide the spring washer (I) over the threaded nipple and then thread nut (H) onto the nipple. Use the wrench (J) to tighten the nut (H).
4. Place the metal plate (K) to the bottom of base (F) and secure with screw (L).
5. Place the felt pad (M) onto the bottom of base (F).
6. Insert harp (C) into the harp saddle (D).
7. Remove finial (A) from top of harp (C), place shade (B) (packed separately) onto the bolt of harp (C) and secure with finial (A).
8. Insert light bulb (not included) into socket.
9. Remove plastic cover (O) from electrical plug (P).
10. Plug lamp into wall outlet.

\*\*\*Clean with a dry, soft cloth only. Use no harsh abrasives or chemical agents.