
## **ASSEMBLY INSTRUCTIONS**



## Parish Floor Lamp Item # TOB 1152

INSPECT ITEM CAREFULLY BEFORE ATTEMPTING TO INSTALL. IF THERE IS ANY DAMAGE OR OBVIOUS DEFECT. DO NOT INSTALL. ITEM MAY NOT BE RETURNED ONCE IT HAS BEEN INSTALLED. NOTE: CAREFULLY UNPACK EACH PIECE IN TOP LAYER OF PACKING PRIOR TO **REMOVING. RETAIN ALL PACKING MATERIAL UNTIL INSPECTION AND INSTALLATION ARE FINAL.** 

\_\_\_\_\_

- 1. Carefully remove all parts from the box.
- 2. Screw the adjustable riser (C) to the top of the lamp body (D).
- 3. Remove the finial (A) from the adjustable riser (C).
- 4. Place shade (B) to the adjustable riser (C) and secure with finial (A).
- 5. Insert bulbs (not included) into the socket.
- 6. Remove protective plug cover (E) from the plug.
- 7. Plug into a proper electrical outlet and test the fixture.
- 8. Installation is complete.

\*\*\*Clean with a dry, soft cloth only. Use no harsh abrasives or chemical agents.

## VISUAL COMFORT & CO. EST. 1987