


## ASSEMBLY INSTRUCTIONS



## Goodman Medium Hanging Light

Item # TOB5091

**WE RECOMMEND INSTALLATION OF THIS LIGHTING FIXTURE BE DONE BY A LICENSED ELECTRICIAN.**

**WARNING \*\*\* SWITCH OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER BEFORE INSTALLATION.**

**INSPECT ITEM CAREFULLY BEFORE ATTEMPTING TO INSTALL. IF THERE IS ANY DAMAGE OR OBVIOUS DEFECT, DO NOT INSTALL.**

**ITEM MAY NOT BE RETURNED ONCE IT HAS BEEN INSTALLED.**

1. Remove mounting strap with threaded nipple from ceiling loop.
2. Attach mounting strap to outlet box with mounting screws provided.
3. Connect the hot wires from the fixture (SMOOTH) to the hot outlet box wire from the outlet box (usually BLACK). Fasten them together with a plastic wire connector provided and wrap connection with electrical tape.
4. Repeat this procedure for the RIBBED neutral wires from the light fixture to the wire from the outlet box (usually WHITE).
5. Connect the ground wire from the light fixture (bare copper) to the ground wire from the outlet box (usually green or bare copper).
6. Thread ceiling loop onto threaded nipple attached to mounting strap.
7. Slip canopy to ceiling and secure with canopy ring.
8. Attach side opening of shade spider to the threaded section on top socket and tighten with ring.
9. Insert light bulb (not included) into socket.