


ASSEMBLY INSTRUCTIONS



Grande Paris Flea Market Chandelier

Item # CHC 1508

WE RECOMMEND INSTALLATION OF THIS LIGHTING FIXTURE BE DONE BY A LICENSED ELECTRICIAN.

WARNING*SWITCH OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER BEFORE INSTALLATION.**

INSPECT ITEM CAREFULLY BEFORE ATTEMPTING TO INSTALL. IF THERE IS ANY DAMAGE OR OBVIOUS DEFECT. DO NOT INSTALL.


ITEM MAY NOT BE RETURNED ONCE IT HAS BEEN INSTALLED.

NOTE: CAREFULLY UNPACK EACH PIECE IN TOP LAYER OF PACKING PRIOR TO REMOVING. RETAIN ALL PACKING MATERIAL UNTIL INSPECTION AND INSTALLATION ARE FINAL.

- Carefully remove all parts from the box.
- A 1/4" threaded nipple must be installed in your outlet box. Then install the threaded nipple (Q) into the outlet box.
- Insert the threaded pipe (A) with nut on both sides into top ring (B) and middle ring (C), then tighten.
- Insert the bottom tube (E) with metal plate (F) and finial (G) into bottom ring (D) and tighten.
- Thread top loop (H) to secure whole assembly fixture.
- Unscrew the threaded collar on the chain end link (U) and attach it to the top ring (H). Close the threaded collar to secure the fixture body.
- Let canopy (S) and lock collar (R) go through the chain (T).
- With the fixture dimension as a guide, shorten the chain (T) as needed using a pair of chain pliers.
- Unscrew the threaded collar on the other chain end link (U), raise the fixture then attach chain end link to the ceiling loop (P). Close the threaded collar to secure.
- Unwrap the wiring from the top of the fixture body. Weave the power supply cord and the ground wire through the chain (T).
- When you reach the canopy and ceiling loop, measure the wires then cut. Be certain to leave enough to connect inside of the outlet box.
- Strip the insulation back on the two power supply wires about 5/8".
- Twist the power supply and ground wire together and push through the center hole of the ceiling loop (P).



ASSEMBLY INSTRUCTIONS



TO assemble safety cables:
 1. Join fixture safety cables with safety cable from ceiling.
 2. Wrap both safety cable around the cable lock nut.
 3. Insert screws into both holes on cable lock nut, secure screws with screwdriver.
 4. Push the cable lock nut into outlet box.

Grande Paris Flea Market Chandelier

Item # CHC 1508

WE RECOMMEND INSTALLATION OF THIS LIGHTING FIXTURE BE DONE BY A LICENSED ELECTRICIAN.

WARNING*SWITCH OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER BEFORE INSTALLATION. INSPECT ITEM CAREFULLY BEFORE ATTEMPTING TO INSTALL. IF THERE IS ANY DAMAGE OR OBVIOUS DEFECT. DO NOT INSTALL. ITEM MAY NOT BE RETURNED ONCE IT HAS BEEN INSTALLED.**

NOTE: CAREFULLY UNPACK EACH PIECE IN TOP LAYER OF PACKING PRIOR TO REMOVING. RETAIN ALL PACKING MATERIAL UNTIL INSPECTION AND INSTALLATION ARE FINAL.

14. Connect the fixture ground (bare) wire with the ground wire from the outlet box using wire nut (V). If your house does not have ground wire, then attach this wire to the green grounding screw inside of the outlet box.
IT IS IMPERATIVE THAT THIS FIXTURE BE GROUNDED.
15. Connect the fixture Neutral wire (ribbed, no markings) with the neutral wire from the outlet box using wire nut (V).
16. Connect the fixture Hot (smooth edge, markings) wire with the hot wire from the outlet box using wire nut (V).
DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS OR SAFETY WILL BE COMPROMISED.
17. Tuck these wire connections neatly into the outlet box to secure.
18. Put canopy (S) to ceiling loop (P), and secure with lock collar (R).
19. Hang the glass beads (K) between top hooks (N).
20. Hang the glass beads (L upper) between top ring (B) and middle ring (C).
21. Hang the glass beads (L lower) between bottom ring (D) and metal plate (F).
22. Hang the glass beads (M) between middle ring (C) and bottom ring (D).
23. Insert bulbs (not included) into the sockets.
24. Installation is complete, turn on power at fuse or circuit breaker.

***Clean with a dry, soft cloth only. Use no harsh abrasives or chemical agents.

