
ASSEMBLY INSTRUCTIONS





Item # PB 1005

INSPECT ITEM CAREFULLY BEFORE ATTEMPTING TO INSTALL. IF THERE IS ANY DAMAGE OR OBVIOUS DEFECT. DO NOT INSTALL.

ITEM MAY NOT BE RETURNED ONCE IT HAS BEEN INSTALLED.

NOTE: CAREFULLY UNPACK EACH PIECE IN TOP LAYER OF PACKING PRIOR TO REMOVING. RETAIN ALL PACKING MATERIAL UNTIL INSPECTION AND INSTALLATION ARE FINAL.

- 1. Carefully remove all parts from the box.
- 2. Attach the DC plug (A) to the driver (B).
- 3. Remove protective plug cover (C) from the plug.
- 4. Plug into a proper electrical outlet and test the lamp.
- 5. Assembly is complete.

***Clean with a dry, soft cloth only. Use no harsh abrasives or chemical agents.

To adjust the lamp brightness:

- 1. Single click the driver to turn lamp on.
- 2. Press and hold the driver to achieve desired brightness.
- 3. Single click the driver again to turn lamp off.



